



# Cock Ring

## User Manual




### Specifications

Material	Silicone + ABS
Size	3.52 * 2.96 * 0.89 in
Net Weight	76.1g
Waterproof	IPX6
Working Frequency	10 frequency
Working Time	About 35mins
Noise	< 50db




### Button Introduction

- Press the "G" button for 2s to turn round head on/off, press again to change the frequencies, 10 frequencies change cyclically.



### How to Charge

- Magnetic charging design;
- When the charging cable is attached to the 2 magnets on the product, the indicator light will light up, the button will flash, and the device will start charging.
- It takes 40 minutes to fully charge and can work continuously for 35 minutes. After fully charged, the indicator light stops flashing.



### Cleaning and Maintain

- Clean the product with warm water and soap. It can be washed with hot water to wash away the remaining soap.
- Use a clean lint-free cloth or microfiber towel to dry, so as not to leave fluff.
- Put this product in a dry place, in a clean environment, and keep it separate from other items to avoid children's contact.
- Do not use alcohol to clean this product, because alcohol will corrode the surface of the product and accelerate its aging.
- The waterproof rating of the product is IPX6, which is suitable for playing in water, but in order to prolong its service life, do not immerse it in water for a long time.