

CHROMA

RECHARGEABLE VIBE

For warranty information, latest products, and news visit us at:
nsnovelties.com

CARE


- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with soft, cotton towel and allow to air dry completely.

Product Dimensions: 6.73 x 1.1 x 1.1 (in)
IPX Rating: IPX7
Battery: Lithium Ion
Charge Time: Do not exceed 120 minutes
Run Time: 60 minutes
Modes: 10



PLAY

- * Press & hold button to power on/off.
- * Quick press button to cycle through vibration modes.



CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.

