

FRONT


5

6

1

CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.



CARE

- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with a cotton towel and allow to air dry completely.

Product Dimensions: 7.56 x 1.38 x 1.38 (in)
IPX Rating: IPX6 High pressure water resistant
Battery: Rechargeable
Charge Time: Do not exceed 90 minutes
Run Time: 120 minutes
Modes: 19



techno

KANDI
APP-CONTROLLED
INSERTABLE VIBE

For warranty information,
latest products, and news visit us at:
nsnovelties.com

BACK

2

3

4

SET UP

- * Scan the QR code below to download the App **Whats Sense** or search "**Whats Sense**" on Google Play or App Store to download.



SET UP

- * After **Whats Sense** is downloaded, register and log into the App. (Bluetooth must be on. There is no personal information needed to register.)
- * Press "🔗" in the top right corner of the App.
- * Press "Start Connecting" in the App.
- * Power on the vibe to pair with your mobile device.

PLAY

- * Quick press the power button to power on and cycle through speeds/functions.
- * Press & hold the power button for 2 seconds to power off.

