

FRONT

⑤

⑥

①

CARE

- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with a cotton towel and allow to air dry completely.

Product Dimensions: 2.36 x 2.44 x 1.73 (in).
Remote: 2.99 x 1.5 x 0.43
IPX Rating: IPX7 Waterproof 30 min. immersion 3 ft.
Remote: IPX4 Splashproof
Battery: Rechargeable,
Remote: Rechargeable
Charge Time: Do not exceed 120 minutes
Run Time: 60 minutes
Modes: 10



For warranty information,
latest products, and news visit us at:
nsnovelties.net

Renegade

ROCKET RING
VIBRATING COCK RING
& REMOTE

BACK


②

③

④

PLAY

- * Press & hold the power button on the vibe for 2 seconds to power on and enter standby mode.
- * Quick press the power button to activate and to cycle through speeds/functions.
- * Press & hold the power button on the vibe for 2 seconds to power off.



PLAY

- * To use the remote, the vibe must be powered on and in standby mode.
- * Quick press the power button to activate vibration function.
- * Quick press the < or > buttons to cycle through the vibration modes.
- * Quick press the + button to increase the vibration intensity.
- * Quick press the - button to decrease the vibration intensity.



CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.

