

Product Specifications:

Material: Silicone+ABS Battery: Rechargeable Li-ion battery 220mAh Voltage: 220mAh Number of Vibrations: 7 User time: 90min in highest level,150mins in lowest level. Sound Level: <60db

CHARGING INSTRUCTIONS

This vibrator arrives with a partial battery charge of about 30%. It is recommended to use up the partial battery energy before charging the toy for the first time. It is also recommended to fully charge toy the first

Toy for the first time. It is also recommended to fully charge toy the first 3 times in order to maximize battery life.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input. Initial and subsequent charges will take about 60 minutes to complete. The indicator light will flash while device is charging and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

> INSERT CHARGER

Charge lasts for about 150 minutes of play time on the lowest level of vibration, and about 90 minutes on the highest level. This toy operates at a sound level of less than 60db with a rechargeable 220mAh lithium HERE battery, at 3.7V.

USB RECHARGEABLE

INSTRUCTIONS FOR USE

This toy has a convenient 1-button control panel at the bottom of its base. This Power Button operates all functions.

To turn toy on, press the Power Button for 1 second.
The Blue LED light will turn on and toy will begin vibrating at its first lowest frequency.
Once the toy is on, press the Power Button again more quickly to cycle through a total of 7 powerful speeds.
To turn toy off, press the Power Button for at least 3 seconds.