

Product Specifications:

Material: Silicone + **ABS Plastic** Battery: Rechargeable lithium battery, 602020 180mAh Voltage: 3.7V Number of Vibrations: 8 User time: 120 minutes Sound Level: 50dbA

CHARGING INSTRUCTIONS

This vibrator arrives with a partial charge of about 50% so it is recommended to fully charge before use.


To charge, connect the USB plug into the USB port of your computer or

other output and the DC charger into input at back of toy.
Initial charge will take about an hour and subsequent charges will
take about 2 hours to complete.

The indicator light will flash while device is charging and turn off when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 2 hours of play time at the highest level of vibration and about 3 hours at the lowest level.

This toy operates at a sound level of between 50db with a rechargeable 180mAh lithium battery at 3.7V.



Once the toy is on, press the Power Button again, a single time for each new speed or function for a total of 8. To turn toy off, press Power Button for at least 3 seconds.