

<http://www.genderx.com/>

GENDER X



Product Specifications:

Material: Silicone
Battery: Li-ion battery,
3.7V/240mAh
Voltage: 3.7V
Number of Vibrations: 9
User time: 40-65 minutes
Sound Level: <45 db

CHARGING INSTRUCTIONS

This vibrator arrives with a partial charge, so it is recommended to fully charge before use.

To charge, connect the USB plug into the USB port of your computer or other output and the DC charger onto the two magnetic pins at the side of the toy's base.

Initial charge and subsequent charges take about an hour to complete.

The indicator light will flash while device is charging and turn off when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 40 minutes of play time at the highest level of vibration and about 65 minutes at the lowest level.

This toy operates at a sound level of between 45db with a rechargeable 240mAh lithium battery at 3.7V.

INSTRUCTIONS FOR USE

This toy has a convenient 1-button control at its base. To turn toy on, press the Power Button for at least 3 seconds. The light will turn on and toy will begin

vibrating in both motors at their first lowest frequency. Once the toy is on, press the Power Button again, a single time for each new speed or function for a total of 9.

ATTACH USB CHARGER TO PRONGS



USB RECHARGEABLE

To turn toy off, press Power Button for at least 3 seconds.