

Product Specifications:

Material: TPE + ABS plastic Battery: 3.7V lithium polymer battery, 500mAh

Voltage: 3.7v

Number of Vibrations: 12 User time: 80 mins Sound Level: 50dB

CHARGING INSTRUCTIONS

This vibrator arrives with a partial charge, so it is recommended to fully charge before use.

charge before use.

Connect the USB end of the charging cable into the port of your power source and the other end onto the magnetic charging pins located below the control panel at the base of the toy's handle.

Initial charge will take about 90 minutes, and subsequent charges will

take about an hour to complete. The indicator light will flash while device is charging and remain solid

when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 100 minutes of play time on the lowest level of vibration, and about 50 minutes on the highest level.

This toy operates at a sound level of less than 50db with a rechargeable 500mAh lithium battery at 3.7V.

INSTRUCTIONS FOR USE

This toy has a convenient 2-button control at its center line.
To turn motor on, press the left Plus Button for at least 2 seconds. The blue indicator light will turn on and vibration will begin at its lowest

1111



press the Minus Button for at least 2 seconds.



USB RECHARGEABLE