

Product Specifications: Category: Vibrator User: Women Material: ABS+PC+Silicone Material: ABS+PC+Silicone Finish: Pantone 324 5. Size: H:4.17 W: 2.68 D:3.99 Battery: Lithium polymer battery 3.7V 450mAH Voltage: 3.7V Number of Vibrations: 8-frequency vibration frequency, eight frequencies for motor vibration User time: The highest frequency works for 1.5 hours Sound Level: 56dbA



## CHARGING INSTRUCTIONS

This vibrator arrives to you with a 70% charge, so there is no need to charge it fully before use.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input.

Initial charge will take about 2 hours, and subsequent charges also take about 2 hours to complete.

The indicator light will flash while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of

Charge lasts for about 90 minutes of play time on the lowest vibration level, and about 40 minutes of play time on the highest level.

Toy vibration stops completely when charge gets below 2.4V.

This toy comes with a Li-ion rechargeable battery and operates at 3.7V. It vibrates at a sound level of 50-60 db.

INSTRUCTIONS FOR USE
This toy has a 3-button control panel.
Press the bottom power button for at least 2 seconds to turn the toy on. Turn the toy off by pressing this button again quickly.
The middle button controls the vibrations and functions of the small motor in the clitoral stimulator.
The top button controls the vibrations and functions in the super powerful shaft motor.