

Product Specifications:

Material: Silicone & ABS Battery: 700maH

Voltage: 5V

Number of Vibrations: 10
User time: 45 - 90 Minutes

Sound Level: ≤ 50dB

CHARGING INSTRUCTIONS

This vibrator arrives with a partial charge, so it is recommended to charge before first use. Initial charge will take about an hour, subsequent charges will take about 2 ½ hours to complete.

Connect the USB plug into a power source and the other end of the DC charger onto the magnetic charging pins located at the back of the toy's handle.

The indicator light will flash while device is charging and turn solid when toy is fully charged. There is no danger of battery damage by

ully charged. There is no danger of battery damage by overcharging but it's not recommended to overcharge for long periods of time.
Charge lasts for about 90 minutes of play time on the

Charge lasts for about 90 minutes of play time on the lowest level of vibration, and about 45 minutes on the highest level.

This toy operates at a sound level of about 50db with a 700mAh lithium battery at a voltage of 3.7.

INSTRUCTIONS FOR USE

This butterfly vibrator is operated with a 3-button panel located on the front of the handle. The center button powers the toy on, the top button operates the vibration in the main shaft and the bottom button operates the vibration in the butterfly piece.

Turn the toy on by pressing the center button for about 3 seconds. The LED light will turn on and both motors will be in standby. Press the top button to engage vibration in the main shaft. It will begin in its lowest frequency. Press the button again to cycle through a total of 10 vibration speeds and patterns. To pause shaft vibration, press the button for 3 seconds. Press the button button to engage vibration in the butterfly. It will begin in its lowest frequency. Press this button again to cycle through a total of 10 vibration speeds and patterns. To pause shaft vibration, press the button for 3 seconds.

Turn the toy off by pressing the center button for about 3 seconds.

ATTACH USB CHARGER TO PRONGS

USB RECHARGEABLE