

SELOPA

SEX | LOVE | PASSION

<http://www.selopa.com/>



Product Specifications:

Material: Silicone & ABS

Battery: Lithium battery

Voltage: 3.7V

Number of Vibrations: 10

User time: 50 - 70 Minutes

Sound Level: <45db

CHARGING INSTRUCTIONS


It is recommended to charge this toy before first use.

Charging will complete in about 2 hours. Connect the USB

cable to a power source at one end and plug the other end into the port at the base of the toy. An indicator light means the toy is charging.

Battery charge lasts for about 70 minutes on the lowest frequency, and about 50 minutes on the highest frequency. Vibration will slow first before stopping completely. This toy operates at a sound level of about 45db at 3.7V.

INSERT
CHARGER
HERE



INSTRUCTIONS FOR USE

1. Press the button at the toy's base for 2 seconds to turn the toy on. The button will light up and toy will begin vibrating at its first lowest frequency.
2. Press button again to cycle through 3 speeds & 7 patterns.
3. To turn toy off, press button for at least 2 seconds. Vibration will stop and light will turn off.

USB RECHARGEABLE