


Product Specifications:

Material: Silicone & ABS
Battery: Polymer Li-ion Battery
601230 3.7V 200mAh 0.74Wh 4.0g
Voltage: 3.7V
Number of Vibrations: 7
User time: 45 − 60 minutes
Sound Level: ≤60Db

CHARGING INSTRUCTIONS

USB RECHARGEABLE

It is recommended to use up the battery charge on this toy before first charge. Repeat this cycle 3 times to ensure long battery life. To charge, connect the USB plug into a power source and the DC charger into the port at the side of the base. Charges take about 75 minutes each to complete. The indicator light will flash while device is charging and stay constant when toy is fully charged.



more quickly to cycle through 7 vibration speeds and patterns.
4. To turn toy off, press

4. To turn toy off, press button for 3 seconds. The light will turn off and all vibration will cease.